


BALL CARRYING CART



← The Ball Cart is supplied fully assembled. Take the folded Ball Cart out of the packaging and position it with the 4 castors flat on an even surface.




← Hold the two ends of the Ball Cart and slowly open until they extend no further.

To Unfold, follow procedures 1 to 4

There are two metal locking arms positioned one on each side of the Ball Cart.



To secure/lock, push down the locking arms at the centre with the palm of the hand until the stud locks into the recess.



To fold back, follow procedures 5 to 6



← Carefully lift up each of the two studs on each locking arm until they are released.



← Hold the two ends of the Ball Cart and slowly push together until it collapses and then packed back into the carton.

IMPORTANT: THIS ITEM TO BE UNFOLDED AND FOLDED BY ADULTS ONLY.