

Electro Sharpener


User Manual



Please read this user manual carefully before use and keep it properly for future use.

Disassembly Method Of Grinding Head


As shown in the right figure,
1. Press the disassembly button to the bottom with your right thumb first.
2. Grasp the grinding head with your left hand and pull it out on the right side.



Product Parameters

Material:ABS
Working voltage: 3.7V
Charging voltage: DC/5V
Battery capacity: 500mAh
Rated power: 5W
Charging time: 2h

HOW TO SHARPEN YOUR POINTS



1. After fully charged, Press the Switch button for 3 to 4 seconds to activate the machine.
2. Select the speed of the grinding head by pressing the Switch button, there will be 2 speed levels available.
3. Sharpen your points with the spin(Switch button is facing you), do not hold the points against the spin otherwise the point could be pulled down into the sharpener.
4. Press the Switch button for 3 to 4 seconds to turn off the machine after the points are perfectly sharpened.

Charge Method

1. Turn off the power supply of the product.
2. Insert the small end of the charging cable that comes with this device into the USB charging port of the product, and plug the other end into the charger.
3. During the charging process, the product indicator light will flash, and it will remain on for about 2 hours to charge when fully charged.

Troubleshooting

Fault Phenomenon	Processing Method
Not Turning On	Please insert the USB charging cable. If the product flashes, it indicates that the product is out of battery.
Grinding Head Difficult To Disassemble	When disassembling the grinding head, first press the disassembly button to the bottom with force, and then pull the grinding head outward.
Unable To Charge	Replace the charging cable or charger.
Grinding Head Blockage	Reduce the pressure when using

Warning

This is not a toy -children should not use this product without the supervision of an adult.